


BRH-1USD & 5USD SUPER VIBRATION-PROOF RIVETING HAMMER

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity				
Common Parts				#51	990-045-0	O-Ring (P48A)	1	Components for BRH-1USD(H) & 5USD(H)							
# 2	180-091-6	Air Inlet Bushing	1	#52	990-047-0	O-Ring (P50A)	1	#13	708-567-9	Bushing (H)	1				
# 3	201-108-1	Valve Plug	1	#53	990-860-0	O-Ring (P48A) (Vibration-proof)	1	#17	709-011-3	Handle	1				
# 4	235-885-0	Silencer Assembly	1	#54	990-861-0	O-Ring (P50A) (Vibration-proof)	1	#18	709-025-3	Casing	1				
# 5	508-914-4	Self-Locking Lever Assembly	1	#55	990-918-0	O-Ring (SNS-20)	1	#20	709-562-3	Stopper	2				
#14	708-682-8	Buffer Bushing	1	#56	990-934-0	O-Ring (SNS-44)	1	ACCESSORY TABLE							
#15	708-834-8	Vibration-proof Rubber (1 less for BRH-1UD)	3	#57	990-989-0	O-Ring (SNS-60)	1	This table shows you what parts will come with the tool.							
#21	709-740-2	Pipe	1	Components for BRH-1USD(R)&(H)				Index No.	Code No.	Parts Name	Qt.	Short form model names			
#22	709-840-2	Handle Cover	1	# 6	705-195-1	Main Valve	1					USD(R)	USD(H)	5USD(R)	5USD(H)
#27	710-782-8	Exhaust Deflector	1	# 7	705-196-1	Valve Box	1	1	174-790-0	Supension Bail	1	○	○	○	○
#30	711-767-7	Casing Cover	1	# 8	705-197-1	Valve Box Cover	1	10	705-810-1	Retainer Spring (Small)	1	○	○		
#31	711-805-7	O-Ring Cover	1	# 9	705-546-1	Piston	1	28	710-812-1	Retainer Spring (Large)	1			○	○
#32	850-157-1	Valve Bushing	1	#11	708-286-8	Cylinder	1	34	876-179-1	Retainer Spring (Flat)(L=32)	1	○	○	○	○
#33	850-158-1	Valve	1	Components for BRH-5USD(R)&(H)				35	920-021-0	Round Head Rivet Set (3.0)	1	○			
#39	969-449-0	Pin (G) (3×6)	2	#19	709-286-4	Cylinder	1	36	920-040-0	Round Head Rivet Set (6.0)	1			○	
#40	970-228-0	Pin (H) (3×28)	1	#23	710-195-1	Main Valve	1	37	920-800-0	Flat Head Rivet Set (Large)	1	○		○	
#41	973-124-0	Roll Pin (3×24)	1	#24	710-196-1	Valve Box	1	38	940-116-0	Air Hose Nipple (NPT1/4X3/8)	1	○	○	○	○
#42	976-151-0	Spring (7×16) (0.7)	1	#25	710-197-1	Valve Box Cover	1	Components for BRH-1USD(R) & 5USD(R)							
#43	979-015-0	Inner Snap Ring (22)	1	#26	710-546-2	Piston	1	#12	708-567-8	Bushing (R)	1				
#44	979-127-0	Outer Snap Ring (30)	1	Components for BRH-1USD(R) & 5USD(R)				#16	709-011-2	Handle	1				
#45	980-005-0	Round Head Notch (2.5)	1	#12	708-567-8	Bushing (R)	1	#29	711-025-7	Casing	1				
#46	980-006-0	Round Head Notch (3)	1	#16	709-011-2	Handle	1								
#47	980-010-0	Flat Head Notch (3)	1	#29	711-025-7	Casing	1								
#48	981-206-0	Ball (1/4)	1												
#49	990-008-0	O-Ring (P10)	2												
#50	990-027-0	O-Ring (P28)	1												

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-581-19-06-26-1002