


UG-45H DIE GRINDER

EXPLODED VIEW



PARTS LIST

#516-984-3 Handle Body Assembly consists of parts marked with " × " remarks in the parts list.

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	203-108-1	× Valve Plug	1	#15	516-412-4	Chuck Nut	1	#34	982-021-0	Ball Bearing (626)	1
# 2	500-914-7	× Self-Locking Valve Lever Assembly	1	#16	516-782-2	Exhaust Deflector	1	#35	982-100-0	Ball Bearing (6000)	1
# 3	505-291-1	Rear Plate Spacer	1	#17	516-835-4	Filter	1	#36	982-901-0	Ball Bearing (6900)	1
# 4	509-102-2	× Valve Seat	1	#18	516-842-5	Casing Cover	1	#37	990-914-0	O-Ring (SNS-16)	1
# 5	512-288-0	Blade	4	#19	923-170-0	Collet Chuck (6mm)	1	#38	990-918-0	O-Ring (SNS-20)	1
# 6	516-025-4	× Casing	1	#20	923-171-0	Collet Chuck (1/4")	1	#39	990-926-0	O-Ring (SNS-35)	1
# 7	516-065-3	Casing Front Cover	1	#26	970-322-0	× Pin (H) (4×22)	1	#40	990-908-0	O-Ring (SNS-10)	1
# 8	516-091-3	× Air Inlet Bushing	1	#27	973-110-0	Roll Pin (3×10)	2	ACCESSORIES			
# 9	516-285-3	Rear Plate	1	#28	973-122-0	× Roll Pin (3×22)	1				
#10	516-286-3	Cylinder	1	#29	975-042-0	Spacer (13.8×10×3)	1	#21	936-514-0	Spanner (14)	1
#11	516-287-3	Rotor	1	#30	976-232-0	× Spring (9.5×18)	1	#22	936-519-0	Spanner (19)	1
#12	516-289-3	Front Plate	1	#31	978-219-0	Snap Ring (22×1.2)	1	#23	939-104-0	Allen Wrench (5)	1
#13	516-305-3	Rotor Collar	1	#32	979-361-0	Snap Ring (ISTW-20)	1	#24	940-114-0	Air Hose Nipple (NPT1/4×3/8)	1
#14	516-390-3	Wheel Spindle	1	#33	981-210-0	× Ball (3/8")	1				

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-296-20-07-27-0507