


UL40 SERIES OIL-PULSE WRENCHES

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	143-025-0	Handle	1	#32	143-924-0	Name Plate	1	#66	891-565-1	Socket Spindle	1
# 2	147-100-3	Valve	1	#33	930-205-0	Drive Rivet (No.0×2.6)	2	#67	891-559-1	Pipe	1
# 3	147-104-2	Valve Rod	1	#34	944-002-0	Supporting Ring (2.6×4.5×1)	1	#68	891-560-1	Socket Snap Pin	1
# 4	147-107-2	Valve Lever	1	#35	944-003-0	Supporting Ring (3×5×1)	1	#69	975-001-0	Spacer (6×2.8×3)	1
# 5	147-210-2	Reverse Valve	1	#36	944-234-0	Supporting Ring (10×14×1.0)	1	PARTS FOR UL40D			
# 6	147-211-2	Reverse Valve Bushing	1	#37	952-106-0	Allen Head Screw (M4×6)	1	#70	143-350-2	Driver Anvil	1
# 7	09B-212-5	Reverse Lever	1	#38	970-148-0	Pin (H) (2.5×3.8)	1	#71	011-351-1	Bit Sleeve (1/8)	1
# 8	143-091-0	Air Inlet Bushing	1	#39	971-102-0	Pin (2×3.8)	1	#72	011-352-1	Bit Spacer	1
# 9	147-780-3	Exhaust Stack	1	#40	971-123-0	Pin (2×23)	1	#73	143-924-2	Name Plate	1
#10	147-042-2	Silencer	1	#41	973-008-0	Roll Pin (2×8)	2	#74	976-327-0	Spring (13.5×11) (0.9)	1
#11	145-835-6	Filter (K50)	1	#42	973-014-0	Roll Pin (2×14)	1	#75	978-117-0	Snap Ring (11.7×1.0)	1
#12	143-285-0	Rear Plate	1	#43	976-006-0	Spring (3×5) (0.4)	1	#76	981-002-0	Ball (1/8)	1
#13	143-286-0	Cylinder	1	#44	976-457-0	Spring (7×12) (0.9)	1	Parts for (TM)-TYPE			
#14	143-287-0	Rotor	1	#45	976-803-0	Spring (2.8×18) (0.4)WPC	1	#80	852-522-1	Handle	1
#15	143-288-0	Blade (PC)	9	#46	979-324-0	Inner Snap Ring (IRTW-24)	1	#81	852-528-1	Front Plate	1
#16	144-289-0	Front Plate	1	#47	979-353-0	Inner Snap Ring (ISTW-12)	1	#82	851-955-1	Connecting Screw	1
#17	143-036-0	Hammer Casing Connector	1	#47-1	979-405-0	Outer Snap Ring (E2.5)	1	#83	933-250-0	One-Touch Connector SLS-04	1
#18	143-439-0	Front Casing	1	#48	981-002-0	Ball (1/8)	1	#84	935-358-0	Polyurethane Hose TU-0212	1
#19	143-454-0	Socket Spindle	1	#49	981-045-0	Ball (1.5)	8	#85	935-350-0	Polyurethane Hose F-1504	1
#20	143-901-0	Rear Liner Plate	1	#50	982-014-0	Ball Bearing (607)	1	#86	851-967-1	Plug	1
#21	143-902-0	Liner	1	#51	982-901-0	Ball Bearing (6900)	1	#87	933-281-0	One-touch Connector KQ2H04	1
#22	143-319-2	Anvil	1	#52	982-922-0	Ball Bearing (6901ZZ)	1	#88	990-320-0	O-Ring ARP568-003	1
#23	143-440-0	Driving Blade	2	#53	990-306-0	O-Ring (ARP-568-004) (H)	1	ACCESSORIES			
#24	143-974-0	Roller (2.5×21)	2	#54	990-329-0	O-Ring (JW1530-19)	1	#90	939-090-0	Allen Wrench (1.5)	1
#25	143-906-0	Liner Casing Setter	1	#55	990-912-0	O-Ring (SNS-14)	1	#91	940-114-0	Air Hose Nipple (NPT1/4×3/8)	1
#26	143-970-3	Relief Valve	1	#56	990-914-0	O-Ring (SNS-16)	1	#92	143-242-2	Adjuster	1
#27	194-742-3	Oil Plug	1	#57	990-916-0	O-Ring (SNS-18)	1	#93	916-810-0	(+)Double Bit (No.2×75)	1
#28	143-327-1	Anvil Front Spacer	1	#58	990-925-0	O-Ring (SNS-32)	2				
#29	143-790-3	Suspension Ring	1	#59	990-970-0	O-Ring (SNS-2)NOK	2				
#30	147-842-2	Handle Cover	1	#60	992-019-0	SU-Ring (Q10) (NTN)	1				
#31	143-840-0	Casing Protector	1	#61	993-100-0	Rubber Ring (12×16.5×2)	1				

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-505-23-07-12-1009