


UL80 SERIES OIL-PULSE WRENCHES

EXPLODED VIEW



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
# 1	09B-212-5	Reverse Lever	1	#28	147-835-3	Filter (K200)	1	#66	990-306-0	O-Ring (ARP-568-004) (H)	1
# 2	115-036-3	Hammer Casing Connector	1	#29	147-842-2	Handle Cover	1	#68	990-912-0	O-Ring (SNS-14)	1
# 3	115-287-3	Rotor	1	#30	147-974-8	Roller Pin (2.5×30)	2	#69	990-914-0	O-Ring (SNS-16)	1
# 4	115-288-3	Blade (PC)	9	#31	174-790-0	Suspension Bail	1	#70	990-916-0	O-Ring (SNS-18)	1
# 5	115-289-3	Front Plate	1	#32	190-328-6	Anvil Bushing	1	#71	990-930-0	O-Ring (SNS-40)	2
# 6	115-439-3	Front Casing	1	#37	891-300-1	Socket Pin Assembly (3/8)	1	#72	990-970-0	O-Ring (SNS-2) (NOK)	1
# 7	115-440-3	Driving Blade	2	#38	891-567-1	Anvil CP (P) (#12 and #37)	1	#73	990-971-0	O-Ring (SNS-3) (NOK)	1
# 8	115-906-3	Liner Casing Cover	1	#39	930-205-0	Drive Rivet No.0×2.6	2	#74	990-981-0	O-Ring (SNS-29) (NOK)	1
# 9	117-025-2	Handle	1	#47	944-002-0	Supporting Ring (2.6×4.5×1)	1	#75	992-020-0	SU-Ring (Q12) (NTN)	1
#10	117-285-2	Rear Plate	1	#48	944-212-0	Supporting Ring (12×16×1.5)	1	Components for (TM)-TYPE			
#11	117-286-2	Cylinder	1	#49	945-942-0	Hexagon Head Bolt (M4×6)	1	#33	851-955-1	Connecting Screw	1
#12	117-319-2	Anvil	1	#50	952-106-0	Hexagon Head Screw (M4×6)	1	#34	851-967-1	Plug	1
#13	117-840-2	Casing Protector	1	#51	966-099-0	Allen Head Plug (NPT 1/16)	1	#35	852-547-1	Handle	1
#14	117-901-2	Rear Liner Plate	1	#52	970-204-0	Pin (H) (3×6)	1	#36	852-548-1	Front Plate	1
#15	117-902-2	Liner	1	#53	971-123-0	Pin (2×23)	1	#40	933-250-0	One-Touch Connector SLS-04	1
#16	117-924-2	Name Plate	1	#54	973-006-0	Roll Pin (2×6)	1	#41	933-281-0	One-Touch Connector KQ2H04-M5N	1
#17	143-970-9	Relief Valve	1	#55	973-008-0	Roll Pin (2×8)	2	#42	935-350-0	Polyurethane Hose F-1504	1
#18	145-327-7	Anvil Front Spacer	1	#56	973-014-0	Roll Pin (2×14)	1	#43	935-358-0	Polyurethane Hose TU-0212	1
#19	147-042-2	Silencer	1	#57	975-757-0	Adjusting Spacer (18×13×1)	1	#67	990-320-0	O-Ring (ARP-568-003)	1
#20	147-064-6	Plug	9	#58	976-006-0	Spring (3×5)	1	Accessories			
#21	147-091-2	Air Inlet Bushing	1	#59	976-457-0	Spring (7×12)	1	#44	939-091-0	Allen Wrench (1.5)	1
#22	147-100-3	Valve	1	#60	976-811-0	Spring (3.7×31)	2	#45	939-105-0	Allen Wrench (4)	1
#23	147-104-2	Valve Rod	1	#61	979-405-0	Outer Snap Ring (E2.5)	1	#46	940-114-0	Air Hose Nipple (NPT1/4×3/8)	1
#24	147-107-2	Valve Lever	1	#62	981-002-0	Ball (1/8)	1				
#25	147-210-2	Reverse Valve	1	#63	981-045-0	Ball (1.5)	8				
#26	147-211-2	Reverse Valve Bushing	1	#64	982-902-0	Ball Bearing (6901)	1				
#27	147-780-3	Exhaust Stack	1	#65	982-903-0	Ball Bearing (6902)	1				

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-528-19-09-06-0502