


US-50 & 50L SCREW DRIVERS

EXPLODED VIEW



PARTS LIST

Index. No.	Code No.	Parts Name	Quantity	Index. No.	Code No.	Parts Name	Quantity	Index. No.	Code No.	Parts Name	Quantity
# 1	496-025-1	Casing	1	# 30	496-029-1	Gear Casing	1	# 59	487-028-0	Hammer Casing	1
# 2	496-210-1	Reverse Valve	1	# 31	496-445-1	Middle Gear	1	# 60	410-328-1	Anvil Bushing	1
# 3	496-212-2	Reverse Lever	1	# 32	496-465-1	Internal Gear	1	# 61	410-360-1	Hammer Shank	1
# 4	410-091-0	Air Inlet Bushing	1	# 33	496-470-1	Planet Gear	1	# 62	410-362-1	Adjusting Nut	1
# 5	496-782-1	Exhaust Deflector	1	# 34	496-480-1	First Gear Cage	1	# 63	418-347-1	Hammer Spring Spacer	1
# 6	472-835-7	Silencer	1	# 35	496-483-1	Gear Cage Spacer	1	# 64	410-365-1	Hammer	1
# 7	496-106-1	Valve Rod Cap	1	# 36	496-485-1	Second Gear Cage	1	# 65	410-364-1	Driven Clutch	1
# 8	496-285-1	Rear Plate	1	# 37	496-028-1	Hammer Casing	1	# 66	410-366-1	Driving Clutch	1
# 9	496-286-1	Cylinder	1	# 38	430-364-1	Driven Clutch	1	# 67	410-319-2	Anvil	1
# 10	496-287-1	Rotor	1	# 39	430-365-1	Hammer	1	# 68	428-057-1	Bit Casing	1
# 11	496-288-1	Blade	5	# 40	430-362-1	Adjusting Nut	1	# 69	418-356-1	Bit Band	1
# 12	496-289-1	Front Plate	1	# 41	431-360-1	Hammer Shank	1	# 70	972-029-0	Needle Roller (2.5×10)	2
# 13	010-790-1	Suspension Ring	1	# 42	430-347-1	Adjusting Nut Lock	1	# 71	975-222-0	Spacer (28×24×1)	1
# 14	945-001-0	Allen Head Bolt (M3×10)	1			Washer	1	# 72	976-058-0	Spring (4.5×11×0.4)	1
# 15	971-107-0	Pin (2×7)	1	# 43	478-318-0	Pilot Pin	1	# 73	976-485-0	Spring (20.2×14×1.6)	1
# 16	973-108-0	Roll Pin (3×8)	2	# 44	478-319-0	Anvil	1	# 74	981-002-0	Ball (1/8)	6
# 17	977-157-0	Cone Spring (7×11×20)	1	# 45	430-356-1	Bit Band	1	# 75	981-002-0	Ball (1/8)	1
# 18	981-003-0	Ball (5/32)	1	# 46	478-057-0	Bit Casing	1	# 76	982-100-0	Ball Bearing (6000)	1
# 19	981-004-0	Ball (3/16)	1	# 47	972-029-0	Needle Roller (2.5×10)	3	ACCESSORIES			
# 20	981-008-0	Ball (5/16)	1	# 48	972-032-0	Needle Roller (2.5×11)	2	# 77	430-057-1	Bit Casing	1
# 21	982-015-0	Ball Bearing (608)	1	# 49	976-070-0	Spring (4.9×28)	1	# 78	917-400-0	Finder	1
# 22	982-101-0	Ball Bearing (6001)	1	# 50	976-539-0	Spring (23×13.5)	1	# 79	976-358-0	Spring (14.4×26)	1
# 23	982-033-0	Ball Bearing (696)	1	# 51	979-109-0	Outer Snap Ring (#12)	1	# 80	916-810-0	(+) Double Bit (No 2×75)	1
# 24	990-005-0	O-Ring (P7)	1	# 52	981-002-0	Ball (1/8)	15	# 81	916-030-0	(-) Bit (5×56)	1
# 25	990-006-0	O-Ring (P8)	1	# 53	981-003-0	Ball (5/32)	6	# 82	940-113-0	Air Hose Nipple (NPT1/4×1/4)	1
# 26	990-922-0	O-Ring (SNS28)	1	# 54	982-101-0	Ball Bearing (6001)	1	# 83	496-779-0	Exhaust Stack Bushing Connector	1
# 27	496-840-1	Casing Protector	1	PARTS FOR US-50L				# 84	935-380-0	Exhaust Hose with Cuffs	1
# 28	976-033-0	Spring (3.6×7×0.5)	1	# 55	496-104-3	Valve Rod	1	# 85	934-150-0	Leader Hose Assembly	1
PARTS FOR US-50				# 56	496-465-3	Internal Gear	1				
				# 57	496-470-3	Planet Gear	2				
# 29	496-104-1	Valve Rod	1	# 58	496-480-3	Gear Cage	1				

When ordering spare parts, please specify tool type, code numbers and parts names.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-442-04-02-29-2003