

US-LT40-03C(P), -05C(P) & -08C(P) SCREW DRIVERS

EXPLODED VIEW

Wider torque coverage by subdivided torque springs application by models

Index	Spring Tension	Abbreviated model names		
		03C(P)	05C(P)	08C(P)
#90	Strong	●	○	○
#91	↑	○	▲	▲
#92	Weak	▲	▲	▲

○ =Standard, ▲ =Option, and ● =Avoid the use

PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
Common Parts				#79	973-118-0	Roll Pin (3×18)	1	#17	461-441-8	Angle Casing	1
#1	010-790-1	Suspension Bail	1	#80	975-106-0	Spacer (18.5×11×1)	1	#18	461-488-7	Angle Head Casing Cover	1
#2	161-835-4	Filter (K-50)	3	#84	975-768-0	Adjusting Spacer (19×16.2×t)	1	#76	972-216-0	Roller Pin (6×16)	1
#3	259-100-0	Valve	1	#87	976-058-0	Spring (4.5×11)	1	#81	975-113-0	Spacer (19×15×1.5)	1
#4	259-254-0	Shut-off Valve	1	#88	976-147-0	Spring (7×12)	1	#83	975-593-0	Round Plate (10×1)	1
#5	444-106-8	Valve Rod Cap	1	#89	976-346-0	Spring (2.9×6.35)	1	#86	975-787-0	Adjusting Spacer (26×24×t)	1
#6	461-025-6	Casing	1	#90	976-515-0	Spring (22.7×28) (2.6)	1	#89	976-346-0	Spring (2.9×6.35)	1
#8	461-097-6	Air Inlet Connector	1	#91	976-516-0	Spring (22.1×28) (2.3)	1	#101	981-002-0	Ball 1/8	1
#9	461-102-6	Valve Sseat	1	#92	976-517-0	Spring (21.5×31) (2.0)	1	#106	982-870-0	Ball Bearing (6801)	1
#10	461-114-6	Valve Spindle	1	#93	977-071-0	Cone Spring (5.5×11.5×15)	1	#110	988-008-0	Needle Roller Bearing (NK10/12T2)	1
#11	461-291-6	Rear Plate Spacer	1	#94	977-155-0	Cone Spring (7×10×35)	1	#112	988-380-0	Needle Roller Bearing (F68)	1
#12	461-344-6	Cam Retainer	1	#95	979-190-0	Outer Snap Ring (22)	1	For US-LT40-08C(P)			
#19	461-567-6	Bushing	1	#96	979-326-0	Inner Snap Ring (IRTW-26)	1	#28	469-420-5	Driving Gear	1
#25	463-104-7	Valve Rod	1	#97	979-351-0	Inner Snap Ring (ISTW-10)	1	#29	469-421-5	Driving Gear Bushing	1
#26	467-285-7	Rear Plate	1	#100	981-001-0	Ball 3/32	2	#30	469-430-8	Driven Gear (P)	1
#27	469-081-6	Locking Nut	1	#101	981-002-0	Ball 1/8	1	#31	469-431-6	Driven Gear Spindle	1
#35	471-318-5	Pilot Pin	1	#102	981-004-0	Ball 3/16	5	#32	469-441-7	Angle Casing	1
#36	471-670-7	Band	1	#103	982-035-0	Ball Bearing 698	1	#33	469-488-5	Angle Head Casing Cover	1
#37	471-764-7	Notch Pin	1	#104	982-063-0	Ball Bearing 606ZZ	1	#82	975-590-0	Round Plate (6.3×1)	1
#38	472-029-7	Gear Casing	1	#105	982-100-0	Ball Bearing 6000	1	#85	975-771-0	Adjusting Spacer (20×18×t)	1
#39	472-211-7	Reverse Valve Bushing	1	#109	987-039-0	Miniature Ball Bearing R1560ZZ	1	#89	976-346-0	Spring (2.9×6.35)	1
#40	472-257-8	Regulating Screw	1	#113	988-460-0	Needle Roller Bearing HK1210T2	1	#99	981-000-0	Ball (1/16)	26
#41	472-286-7	Cylinder	1	#114	990-911-0	O-Ring (SNS-12)	1	#101	981-002-0	Ball (1/8)	1
#42	472-287-7	Rotor	1	#115	990-923-0	O-Ring (SNS-26)	1	#111	988-090-0	Needle Roller Bearing (B-24)	1
#43	472-288-0	Blade (PC)	5	#116	996-424-0	Packing (16×9×2)	1	Parts for US-LT40-03C(P)			
#44	472-289-7	Front Plate	1	Gear Section				#7	461-082-8	Connecting Screw	1
#46	472-346-5	Cam	1	For US-LT40-03C(P)				#13	461-369-7	Clutch Casing	1
#47	472-370-7	Clutch Casing Sleeve	1	#50	472-460-5	Rotor Gear	1	#20	461-654-7	Cam Guide	1
#48	472-375-7	Cam Ring	1	#52	472-470-5	First Planet Gear	6	#21	462-319-9	Anvil	1
#49	472-379-8	Retainer	1	#55	472-480-5	First Gear Cage	1	#22	462-466-9	Second Internal Gear	1
#59	472-562-8	Spring Holder	1	#57	472-485-5	Second Gear Cage	1	#23	462-471-9	Second Planet Gear	3
#60	472-782-7	Exhaust Deflector	1	#63	496-483-1	Gear Cage Spacer	1	#24	462-487-9	Second Gear Cage Spacer	1
#61	472-807-7	Spacer	1	#74	972-089-0	Roller Pin (3×8)	6	#75	972-090-0	Roller Pin (3×10)	3
#62	480-091-8	Air Inlet Bushing	1	For US-LT40-05C(P) & 08C(P)				#98	979-353-0	Inner Snap Ring (ISTW-12)	2
#63	496-483-1	Gear Cage Spacer	1	#51	472-460-7	Rotor Gear	1	#107	982-901-0	Ball Bearing (6900)	1
#64	553-103-1	Valve Rod Bushing	1	#53	472-470-7	First Planet Gear	3	#108	982-902-0	Ball Bearing (6901)	1
#65	700-107-1	Valve Lever	1	#54	472-471-7	Second Planet Gear	3	Parts for US-LT40-05C(P) & 08C(P)			
#66	893-057-1	Reverse Valve	1	#56	472-480-7	First Gear Cage	1	#14	461-369-8	Clutch Casing	1
#69	944-019-0	Back-up Ring (P-19)	1	#58	472-485-7	Second Gear Cage	1	#34	469-807-5	Spacer	1
#70	969-470-0	Pin (2×8)	1	#63	496-483-1	Gear Cage Spacer	1	#45	472-319-7	Anvil	1
#71	970-092-0	Pin (H) (2×5.5)	1	#74	972-089-0	Roller Pin (3×8)	6	Accessories			
#72	970-105-0	Pin (H) (2×24)	1	Angle Head Section				#67	939-402-0	Manual Driver (No. 2)	1
#73	970-108-0	Pin (H) (2×26.8)	1	For US-LT40-03C(P) & 05C(P)				#68	940-113-0	Air Hose Nipple (NPT 1/4×1/4)	1
#74	972-089-0	Roller Pin (3×8)	6	#15	461-420-7	Driving Gear	1				
#77	973-006-0	Roll Pin (2×6)	1	#16	461-430-8	Driven Gear (P)	1				
#78	973-010-0	Roll Pin (2×10)	2								

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-419-20-01-20-1002